



Samsung NP700Z5AH Optical Drive Replacement

This guide provides detailed steps to remove...

Written By: Erik



INTRODUCTION


This guide provides detailed steps to remove and replace the device's Optical Drive in the Samsung NP700Z5AH device.

TOOLS:

Phillips #00 Screwdriver (1)


Tweezers (1)

Step 1 — Battery



- Remove the ten 6.6mm Philips#00 screws securing the lower case to the upper case.

Step 2





- Using your fingers, pinch the edge of the SD card and pull to remove it.

Step 3



- Wedge your fingers in between the upper case and the lower case
- Gently pull the lower case away from the upper case to remove it


Step 4



- Using [tweezers](#) or your fingertips, carefully pull on the battery connector to disconnect it from the motherboard.



⚠ Be sure to pull straight backwards, or you risk damaging the wires.

Step 5



- Remove the two 4.4mm Phillips#00 screws from the battery case.



Step 6



- Place your fingers on the corner sections of the battery.
- Lift to remove the battery.



⚠ If you choose to use tools to remove the battery be careful not to damage it. A damaged lithium-ion battery may leak dangerous chemicals and/or catch fire. Use only plastic pry tools.

Step 7 — Optical Drive




- Using your fingers, grasp the ribbon cable connected to the optical drive and pull it straight out to disconnect it.
- ☑ To reinstall the cable, hold it near the end and push it straight into the connector, being careful not to kink the cable.

Step 8




- Using the Phillips#00 remove the three 3.5mm screws that secure the speaker to the bottom case.

Step 9




- With your fingers, grasp the edges of the speaker and slide it up and away from the fan to lift it out of the case.

Step 10



- With the Phillips#00, remove the following screws holding the optical drive to the metal brackets.
- Six 2.4mm screws
- One 3.4mm screw
- Using your fingers, grasp the metal brackets and remove them.

Step 11



- Place your fingers on either side of the optical drive and slide it away from the fan to remove it.

To reassemble your device, follow these instructions in reverse order.