



Game Boy Color LCD Ribbon Cable Replacement

Removing the ribbon cable provides unhindered...

Written By: Nick Katsantonos



INTRODUCTION

Removing the ribbon cable provides unhindered access to the inner workings of the Game Boy Color.

TOOLS:

Spudger (1)

Tri-point Y0 Screwdriver (1)

Step 1 — Battery




- Locate the battery compartment on the back of the Game Boy Color.
- Push down on the tab and hinge the cover downwards and outwards to remove the battery cover.

Step 2




- Remove the batteries from the battery compartment.

Step 3 — Back Housing



- Using a Y1 screwdriver, remove the six screws on the back of the device as pictured. The bottom two screws are located inside of the battery compartment.

Step 4



- Gently lift and separate the back housing from the rest of the device. Now you've got the back housing out!

Step 5 — LCD Ribbon Cable



- Push up on the tabs on either side of the ribbon with a spudger.

Step 6



- Gently remove the ribbon cable from the port

To reassemble your device, follow these instructions in reverse order.