



# VTech InnoTab 2 Battery Replacement

Replace dead batteries to restore power to VTech InnoTab 2.

Written By: Mark Lefcourt



---

## INTRODUCTION

A quick guide on how to replace dead batteries for your VTech InnoTab 2. This device requires 4 AA batteries to run without an AC adaptor. No tools are required to complete this guide.

---



### PARTS:

- [4 AA batteries](#) (1)
-

## Step 1 — Battery



- Apply slight pressure and slide the button above the battery cabinet to the right to open.
- Remove battery cabinet cover by sliding away from the center of device.
- ⓘ This device requires 4AA batteries to function without the AC adaptor.

To reassemble your device, follow these instructions in reverse order.