



Gateway LT41P10u Battery Replacement

How to replace a Gateway LT41P10u battery.

Written By: Michael Smith



INTRODUCTION

In any computer repair, removing the power source will prevent many dangerous situations. It should be the first thing you do whenever you want to make any repair or replacement.

Step 1 — Battery



- Place the laptop upside down on a flat surface so you can see the battery.

Step 2



- Pull the two marked tabs towards the outside of the computer to unlock them.

Step 3



- While keeping both of the tabs in the unlocked position, grab the battery and pull outwards, until the battery slides out from the rest of the computer.

To put the battery back, just slide it back into its slot and make sure that both locking tabs are locked.