



Bissell Powerglide Cordless Debris Canister Funnel Replacement

A quick debris canister funnel replacement guide for the Bissell Powerglide Cordless vacuum cleaner.

Written By: Joseph Adam Johnson



INTRODUCTION

A quick debris canister funnel replacement guide for the Bissell Powerglide Cordless vacuum cleaner.



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Filter



- Remove the gray motor unit by twisting it so that the black triangle moves from the "locked" to the "unlocked" position.

Step 2



- Remove the filter from the dirt canister.

Step 3 — Debris Canister Funnel



- Separate the cyclone assembly from the dirt tank by twisting the pieces counterclockwise.

Step 4



- Use a Phillips head screwdriver to remove the three screws from the bottom of the cyclone assembly.
- Remove the bottom of the assembly.

Step 5



- Twist the clear plastic capsule with the fins counterclockwise to remove it.

Step 6



- Twist the blue parts counterclockwise with a good amount of force to remove them.

To reassemble your device, follow these instructions in reverse order.