



Bissell Powerglide Cordless Filter Cleaning or Replacement

Bissell Powerglide Cordless Filter Cleaning or Replacement.

Written By: Joseph Adam Johnson



INTRODUCTION

Bissell Powerglide Cordless Filter Cleaning or Replacement.



TOOLS:

- [Fingers](#) (1)



PARTS:

- [Bissell Powerglide Cordless Filter](#) (1)

Step 1 — Filter



- Remove the gray motor unit by twisting it so that the black triangle moves from the "locked" to the "unlocked" position.

Step 2



- Remove the filter from the dirt canister.

To reassemble your device, follow these instructions in reverse order.