



Hoover Power Scrub FH50150 Handle Replacement

This Guide will show you how to replace the handle.

Written By: Leo



INTRODUCTION

This Guide shows you how to replace the handle.

TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Handle Replacement



- Push the button on the top of the clean water/solutions tank and pull on the handle below the button simultaneously. The tank should easily swing out.

Step 2



- Using the screwdriver, unscrew both of the screws on the backside of the handle.

Step 3



- Pull the handle upwards. It should freely slide away from the base of the machine.

To reassemble your device, follow these instructions in reverse order.