



Lenovo Edge Thinkpad E431 RAM Replacement

This guide will show how to replace the Memory Module (RAM) in the Lenovo Edge Thinkpad E431.

Written By: Nathan Behan



This document was generated on 2020-11-16 03:03:31 PM (MST).

INTRODUCTION

This is a guide made to show how to replace the RAM in a Lenovo Edge Thinkpad E431.



TOOLS:


- [Phillips #00 Screwdriver](#) (1)



PARTS:


- [The Replacement Memory Module/s](#) (1)

Step 1 — Bottom Panel



- Close the device and remove all power cables.
- Lay the laptop flat with the bottom facing upwards.

Step 2




- Remove the four 2mm Phillips #00 screws from the bottom panel.

Step 3




- Remove the back panel of the device.

Step 4 — RAM



- Using your fingers, spread the clips away from the RAM module.
- ⓘ The RAM should "pop" out of its socket.

Step 5



- Pull the RAM out at a 30 degree angle.

To reassemble your device, follow these instructions in reverse order.