



Jam XT HX-P430 Disassembly

This a quick disassembly of the Jam XT HX-P430 Ruggedized Speaker.

Written By: Wolf Andrew



 **TOOLS:**

- Phillips #1 Screwdriver (1)
 - Spudger (1)
 - Sharp knife (1)
-

Step 1 — Casing



- You can really take this off however you want but here's a pic.

Step 2 — Speaker Guard



- Using a spudger or similar pry the guard off one side at a time.

Step 3 — Screws!



- Remove the screws for the speaker and the four that are down the holes.
- It isn't necessary but I removed the d-ring as well.

Step 4 — Case



- Remove the black button spacers. (Note: There are 3 spacers I lost one).
- Push the white bottom through the hole and slowly wiggle the blue case off. Be careful not to break the speaker cables.
- Now remove the four screws.

Step 5 — Board and Battery.



- They used black silicone to keep the connectors together so the entire assembly may come off. I suggest making sure you know how they go back together.
- Carefully using a knife try to split the silicone so the connectors come off easily.
- Next remove the four screws holding the board in. (Note: There are two matching pairs.)
- Using the spudger remove the battery from the white plastic.

Step 6 — Finished!



- Yay! It is disassembled.
- (Note: There are 3 spacers I lost one).

To reassemble your device, follow these instructions in reverse order.