# HP Pavilion Sleekbook 15-b000 Screen Replacement

Remove the Screen for future repairs or replace the Screen if damaged.

Written By: Sam Barkley

INTRODUCTION

This guide will go through the steps to replace the screen if it is not displaying anything or the display is distorted.

🔧 TOOLS:

- Phillips #1 Screwdriver (1)
- iFixit Opening Tools (1)

This document was generated on 2020-11-28 06:34:38 AM (MST).

　　　　www.iFixit.com

Step 1 — Battery

- Unplug laptop from adapter and all other devices.

Step 2

- Flip the laptop over with battery facing you.

Step 3

- Slide the battery lock on the right side open.

- Slide the Battery release latch on the left side.

Step 4

- Pull battery out.

Step 5 — Keyboard

- Remove the two 6.5mm Phillips #1 keyboard screws from bottom of laptop.

Step 6

- Push screwdriver through screw hole top pop the keyboard.
- ⓘ Make sure the screen is open.

Step 7

- Pry up the keyboard.

- ⓘ The keyboard is still attached by it's ribbon.

Step 8

- Remove keyboard wire by popping latch under blue plastic

This document was generated on 2020-11-28 06:34:38 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 6 of 11

Step 9 — Case

- Using the spudger to lift up on the white tabs

- Pull horizontally on the blue ribbon to disconnect the cables

Step 10

- Remove the five 5.5mm Phillips #1 screws from the case

This document was generated on 2020-11-28 06:34:38 AM (MST).

© iFixit — CC BY-NC-SA   www.iFixit.com   Page 7 of 11

Step 11

- Remove eight 6.5mm Phillips #1 screws from the back cover

Step 12

- Starting at a top corner, use the pry tool to split the case.

- Slowly work around the case, pulling up gently to release the clips.

Step 13 — Screen

- Remove the four 5.5mm Phillips #1 screws attaching the screen.

Step 14

- Remove the two 3.5mm Phillips #1 screws from the bottom of the screen.

Step 15

- Remove the screen from it's case.

- (i) Screen is still connected to it's case by a wire.

Step 16

- Lay the screen face down on a surface where it ill not scratch

Step 17

- Lift up plastic over latch for the screen.

- Pull the connector away from the screen to disconnect it.

To reassemble your device, follow these instructions in reverse order.