



# HP ProBook 455 G1 Battery Replacement

This guide will assist you in safely and properly removing the battery of your HP ProBook 455 G1 device.

Written By: Jennifer Sexton



## INTRODUCTION

If your battery is not working, needs to cool down, or needs to be taken out for another reason, follow the steps below to remove it properly.

## Step 1 — Battery



- Turn the computer upside down on a flat side, so that you are seeing the underside of the laptop.
- ⚠ Before removing the battery, make sure that the computer is turned off and that the power cord is not plugged into the computer.

## Step 2



- Slide the two battery release latches towards the center of the laptop to release the battery.

### Step 3



- Tilt the battery upward.
- Remove it from the laptop.

To reassemble your device, follow these instructions in reverse order.