Lenovo ThinkPad T410s Keyboard Replacement

This guide will instruct you on how to replace...

Written By: Blake Wilson



INTRODUCTION

This guide will instruct you on how to replace the keyboard on your Lenovo ThinkPad T410s.


TOOLS:

Phillips #0 Screwdriver (1)
Flathead 3/32" or 2.5 mm Screwdriver (1)
Spudger (1)

PARTS:


Lenovo Keyboard - 45N2211 (1)
Lenovo Keyboard - 45N2171 (1)


Step 1 — Battery



- Flip the laptop over.
- Push and hold the locking switch to the left.
- Pull the battery out with your other hand.

Step 2 — RAM





- Remove the single Phillips #0 screw grin the back panel.
- Pull the back panel off.

Step 3








- Pull the metal prongs at the side of the RAM away from each other.

  ⓘ The RAM will pop out of its socket when done correctly.

- Pull the RAM out.

Step 4 — Hard Drive





- Remove the single Phillips #0 screw that secures the hard drive cover.


Step 5






- Flip the black plastic tab out.


Step 6






- Pull the hard drive out.


Step 7 — Keyboard



- Remove the Flathead 2.5mm screw.
- Flip the laptop over.


Step 8





- Wedge the flat end of a spudger, or plastic opening tool, under the end of the keyboard and pry up.

Step 9






- Slide the keyboard out of the way until you can see what's underneath it.

⚠ The keyboard is still attached with a ribbon cable so don't try to fully remove it.

Step 10



- Use the flat end of a spudger to unplug the keyboard connector from the laptop.
- Pull the keyboard out.

To reassemble your device, follow these instructions in reverse order.