

## **Dell Vostro 1088 Battery Replacement**

Written By: Johnathan Hammond



## Step 1 — Battery





- Slide the battery latches apart while at the same time slipping your forefingers into the groove at the center of the battery and pushing outward to disengage the battery from the computer.
  - Lift the battery from the computer.

To reassemble your device, follow these instructions in reverse order.