



# Dell Inspiron 17-3721 Battery Replacement

Over time, laptop batteries will stop holding...

Written By: Zachary Taylor



# INTRODUCTION

Over time, laptop batteries will stop holding their charge and eventually die out. This guide will show how to remove and replace the battery of the device.

## ⚙️ PARTS:

[Dell DL-I5521X4 Battery](#) (1)

### Step 1 — Battery



⚠️ Be sure the laptop is shut off and unplugged from the wall outlet.

- Slide each latch out to unlock the battery.

### Step 2



- Use your thumb to lift the battery out of its slot by lifting the bottom edge of the battery.

---

To reassemble your device, follow these instructions in reverse order.