



Sony Alpha DSLR- A850 Camera strap Replacement

This guide shows how to detach the camera strap from the camera and replace it with a new one

Written By: Walter Littlefield



Step 1 — Camera strap



- Locate strap of camera.
- ⓘ There is a buckle on either side of the strap.
- Pick one side of the strap to start on.

Step 2



- With thumb push the short end of the strap through the buckle creating a loop.

Step 3



- Pull on the loop until the strap comes out of one end of the buckle.

Step 4



- Pull strap from the other side of the buckle until it is completely removed from the buckle.

Step 5



- Hold retaining clamp and pull strap through it.

Step 6



- The strap is now free to pull the rest of the way off of the camera.

To reassemble your device, follow these instructions in reverse order.