![iFixit logo](X iFIXIT)

# Lenovo ThinkPad X61 Battery Replacement

How to remove and replace the battery on a Lenovo ThinkPad X61 laptop.

Written By: Ryan McCarthy

This document was generated on 2020-11-28 06:43:39 AM (MST).

Step 1 — Battery

- The first step to replacing your insufficient battery is to flip your device to the back side, with the battery on top.

- You should then find the battery lock release located in the top left corner, as indicated in the image.

Step 2

- The next step is to simply move the switch from the locked position to the unlocked position.

This document was generated on 2020-11-28 06:43:39 AM (MST).

Step 3

- Next, you find the second lock release switch located under the bottom right of the battery holder as marked in the image.

- Simply move the switch over from the locked position to the unlocked position and pull the battery from its holder. You can now insert the new battery.

To reassemble your device, follow these instructions in reverse order.