



HP Pavilion N3350 Peripheral Component Interconnect (PCI) Replacement

Use this guide to replace the PCI of your device.

Written By: Emily Hatstat



INTRODUCTION

If you are using a sound card, video card, or network card in your laptop, they are inserted into the PCI slot. If they are malfunctioning, they need to be replaced or cleaned. Once the respective replacement is purchased, follow the guide to replace.

TOOLS:

- [Spudger](#) (1)

Step 1 — Peripheral Component Interconnect (PCI)



- Locate the PCI port, it is next to the CD drive on the right side of the laptop.

Step 2



- Use a spudger to open the button that disengages the card from the slot.

Step 3



- Once popped out, press the button and the inserted PCI should eject and be removed easily.
- ⓘ Our laptop contains a NetLINE PC Card that is a primitive Ethernet Network Adapter. This method works for all PCIs inserted to the PCI slot.

To reassemble your device, follow these instructions in reverse order.