

Dell Precision M4600 Base Cover Replacement

Written By: Johnathan Hammond





Phillips #0 Screwdriver (1)

Step 1 — Battery





- Slide the battery release latch into the unlock position.
 - Remove the battery from the system.

Step 2 — Base Cover







- Remove the screws that secure the base cover to the computer.
 - Press the rubber feet towards the rear of the system to disengage the bottom door.
 - Remove the base cover from the computer.

To reassemble your device, follow these instructions in reverse order.