



Dell Precision 7520 Battery Cover Replacement

Written By: Johnathan Hammond



Step 1 — Battery Cover



- Slide the release latch towards the unlock icon to release the battery cover [1].
- Slide and lift the battery cover to remove it from the computer [2].

To reassemble your device, follow these instructions in reverse order.