
SEGA Genesis Flashback Controller Back Cover Replacement

This guide will help you replace the back cover...

Written By: Omar Shorab





INTRODUCTION

This guide will help you replace the back cover of you controller. You'll only need a Phillips #000 screwdriver to complete this guide.

TOOLS:

54 Bit Driver Kit (1)
Magnetic Project Mat (1)
Phillips #000 Screwdriver (1)

Step 1 — Controller Back Cover


- Hold the controller with the bottom plate facing up, and gently remove the top plate that is connected to the motherboard of the controller. Set the top plate aside.
- Remove the screws on the back of the controller with the Phillips #000 screwdriver.

ⓘ Be sure to separate the two plates with the bottom facing up, to keep the buttons from falling out.

To reassemble your device, follow these instructions in reverse order.