



LG G Vista SIM Card Replacement

This guide will help you replace the SIM card of your LG G Vista device.

Written By: Justin Ogihara



INTRODUCTION

This guide will help you replace the SIM card of your LG G Vista phone. You won't be needing any special tools, unless if you're more comfortable using plastic opening tools instead of your fingers.

Step 1 — SIM Card



- Power down and turn off your device.

Step 2



- Using your fingers or a plastic opening tool, remove the back cover from your device.

Step 3



- Using a plastic opening tool or your fingers, eject the SIM card from the device.

To reassemble your device, follow these instructions in reverse order.