



2007-2012 Acura Rdx Tail Light Bulb Replacement

How to replace a tail light bulb on a 2007-2012 Acura Rdx.

Written By: JONG HUN KIM



INTRODUCTION

- Most tail light bulbs on 2007-2012 Acura Rdx vehicles need to be replaced after a decade of use. This is due to the fact that bulbs have a certain life shelf. Driving a vehicle without the tail lights working is a violation against traffic laws and doing so could result in a traffic fine. Another important factor is the safety of passengers present on the road. Driving a vehicle with inadequate visibility could result in an accident since the stopping sight distance will be affected dramatically.
- The average price of replace a tail light bulb on 2007-2012 Acura Rdx vehicles is approximately between 90 to 100 dollars after tax. Nevertheless, if the driver knows how to replace a tail light bulb on 2007-2012 Acura Rdx vehicles, they can do it for around a tenth of the cost expected from automobile repair shops.
- As a precaution, do not proceed the below steps in wet conditions, and take extreme care not put the screw driver or fingers in the bulb socket.

TOOLS:

- [Ratchet](#) (1)
- [Drive Extension Bar](#) (1)
- [5/16" Socket](#) (1)
- [Flathead Screwdriver](#) (1)

PARTS:

- [7443 Bulb](#) (1)

Step 1 — Tail Light Bulb



- Open the trunk.

Step 2



- Clean the area of work by removing any materials in the area.

Step 3



- Remove the bolt covers with the flat head screwdriver from the tail light housing.

Step 4




- Remove bolts with a ratchet, driver extension bar, and 5/16" socket from tail light housing.
- If a ratchet, drive extension bar, and 5/16" socket are not available, a Phillips head screwdriver can be used as a substitute. However, using a Phillips head screwdriver will make the removal of the bolts more challenging.

Step 5



- Remove tail light housing from the car.

Step 6



- Remove the bulb socket from the tail light housing.

Step 7



- Remove the bulb from bulb socket.

Step 8




- Insert new bulb into bulb socket.

Step 9



- Check the new bulb is functioning.

Step 10



- Insert bulb socket back into tail light housing.

Step 11



- Insert tail light housing back into car.

Step 12



- Insert bolt back into the tail light housing with a ratchet, driver extension bar, and 5/16" socket.
- If a ratchet, drive extension bar, and 5/16" socket are not available, a Phillips head screwdriver can be used as a substitute. However, using a Phillips head screwdriver will make the tightener of the bolts more challenging.

Step 13



- Insert bolt covers into the tail light housing.

Step 14



- Check that the tail light housing is secured.

Step 15



- Double check the new bulb is functioning.

Driving a vehicle without the tail lights working is a violation against traffic laws and doing so could result in a traffic fine. Another important factor is the safety of passengers present on the road because driving a vehicle with inadequate visibility could result in an accident since the stopping sight distance will be affected dramatically. Therefore, it is important to have working tail lights. Nevertheless, the average price of replacing a tail light bulb on 2007-2012 Acura Rdx vehicles is approximately between 90 to 100 dollars after tax. Nonetheless, if the driver knows how to replace a tail light bulb on 2007-2012 Acura Rdx vehicles, they can do it for around a tenth of the cost expected from automobile repair shops. The only things to keep in mind when following the steps above is to make sure not to stick the screwdriver or your fingers in the taillight bulb socket to avoid being electrocuted or, serious damage can be caused to the electrical components of the vehicle. In addition, make sure not to perform the fix during wet conditions.