



System76 Serval WS Hard Drive Replacement

How to replace a System76 Serval WS hard drive.

Written By: Oliver Anderson



INTRODUCTION

This guide will show how to replace the hard drive inside your Systems76 Serval WS laptop.



TOOLS:

- [Pro Tech Toolkit](#) (1)
-

Step 1 — Hard Drive



- Remove the three screws attached to the back panel.
- Gently remove the back panel.

Step 2



- Remove the hard drive from the back.
- Remove the four screws that attach the protective plastic case on the drive.
- ☑ Save the protective plastic case as it can be placed on the new drive.

To reassemble your device, follow these instructions in reverse order.