



# HP Elitebook 8460p Back Panel Replacement

Use this guide to remove the access panel on the bottom of the HP Elitebook 8460p.

Written By: Garrett Anderson



## INTRODUCTION

Use this guide to remove the access panel on the bottom of the HP Elitebook 8460p. Removing the panel will grant access to the internal components for repair or replacement and needs to be completed before doing any work on the laptop.

## Step 1 — Back Panel



- On the back of the laptop, slide the right switch toward the outside of the laptop until you hear a click.

## Step 2



- Slide the back shell of the laptop away from the switches until it can be lifted up.
- Lift the shell straight up.

To reassemble your device, follow these instructions in reverse order.