

Open front access panel

This single step is a prerequisite to accessing virtually any component within the printer.

Written By: Tim



Step 1 — Open front access panel



 Open the front access panel by placing your finger in the front slot and pulling gently.

To reassemble your device, follow these instructions in reverse order.