

Brother HL-5240 Drum Unit and Toner Cartridge Replacement

Written By: Guy Patterson



INTRODUCTION

This guide tells you how to remove the drum & toner unit from the printer before you perform any maintenance.

Step 1 — Drum Unit and Toner Cartridge



- Press the front cover release button.
- Keep the button pressed and pull the cover toward yourself.

Step 2







- With the front cover in the downward position, the drum & toner unit will be visible.
- Grab the black-and-yellow handle on the unit. Lift unit up and pull it out of the printer.

To reassemble your device, follow these instructions in reverse order.