



iPhone 5c Pentalobe Screws Replacement

This guide shows how to remove the Pentalobe...

Written By: Sam Goldheart



INTRODUCTION

This guide shows how to remove the Pentalobe screws on your iPhone 5c.

TOOLS:

[P2 Pentalobe Screwdriver iPhone](#) (1)

PARTS:

[iPhone 5c Bottom Screws](#) (1)

Step 1 — Pentalobe Screws



- Use the Pentalobe screwdriver to remove the two 3.8 mm Pentalobe screws near the dock connector.

To reassemble your device, follow these instructions in reverse order.