



iPhone 5s Pentalobe Screws Replacement

This guide will illustrate how to remove the...

Written By: Sam Goldheart



INTRODUCTION

This guide will illustrate how to remove the two Pentalobe screws for your iPhone 5s.

TOOLS:

[P2 Pentalobe Screwdriver iPhone](#) (1)

Step 1 — Pentalobe Screws



- Remove the two 3.9 mm Pentalobe screws next to the Lightning connector.

To reassemble your device, follow these instructions in reverse order.