



LG Optimus L7 P705 Battery/SIM Card Replacement

Replacing the battery and/or SIM card.

Written By: Bruna



INTRODUCTION

The following guide explains how to replace the Battery/SIM card.



TOOLS:

- [iFixit Opening Tools](#) (1)
-

Step 1 — Battery/SIM Card



- Insert a plastic opening tool between the seams of the device and pry the back cover away from the phone.
- Remove the battery and SIM card.

To reassemble your device, follow these instructions in reverse order.