



# HP TouchSmart 15-r015dx Battery Replacement

The HP TouchSmart 15-r015dx has a 3-cell...

Written By: Jacob Kleinsorge



# INTRODUCTION

The HP TouchSmart 15-r015dx has a 3-cell lithium-ion polymer battery that fits nicely on the bottom of the laptop. The battery has easy-release switches in order to remove and reinstall batteries.

## Step 1 — Battery



① Turn off your laptop.

⚠ Ensure your laptop is off.  
Removing the battery while it is on may harm your laptop or yourself.

- Flip over to view the bottom of the laptop in order to gain access the battery and the DVD±RW Drive.

## Step 2



- There are two battery release switches circled.

## Step 3



- slide release switches inward towards each other to release battery.

## Step 4



- after sliding the release switches, pull battery towards yourself to remove battery.

---

To reassemble your device, follow these instructions in reverse order.