



Written By: Chris



INTRODUCTION

This guide shows how to change the battery in a LG 440G flip phone.

The user may need to change the battery if the flip phone is running slow, not turning on, or has lost capability or ability to hold charge. No special skills or tools are required, although you will need to purchase the new battery from LG.

Before beginning to replace the battery, make sure to turn your device off. The guide will help you with this.

Step 1 — Turn off phone.



- Turn the device off.
- To do so, press and hold the red button.

Step 2 — Flip phone.



- Flip the phone over.

Step 3 — Rear cover removal.



- Slide the rear cover downward
- Lift it off to access the battery

Step 4 — Removal of battery.



- Locate the small rounded recess to get access to the battery
- Gently, lift the battery

To reassemble your device, follow these instructions in reverse order.