

Nikon Coolpix P90 Battery Replacement

Replace the battery with a fully charged EN-EL5...

Written By: Elizabeth Kamine



INTRODUCTION

Replace the battery with a fully charged EN-EL5 rechargeable Li-ion battery. It provides 3.7V and 1100mAh. Check your battery to ensure you are replacing with a compatible model.

Step 1 — Camera Base



- Use your finger to push the latch of the compartment door to the center of the camera body, per image 1.
- Push the door open, and remove the existing battery with your fingers, per images 2-3.

To reassemble your device, follow these instructions in reverse order.