



Acer Aspire One ZG5 Battery Replacement

This guide will show you how to install a new battery.

Written By: Doug Gallatin



INTRODUCTION

There is a battery lock and a latch holding the battery in place.



PARTS:

- [Laptop Battery for Acer Aspire ZG5 Series](#) (1)
-

Step 1 — Battery



- Turn the netbook upside down with the battery at the top, facing away from you.

Step 2



- Unlock the battery by sliding the switch located near the left hinge to the left "unlocked" position.

Step 3



- Slide the latch located on the opposite hinge from the lock while pushing the battery up.

To reassemble your device, follow these instructions in reverse order.