

# Sony Ericsson z300 Front Dark Grey Case Replacement

Remove the case in order to access the Screens.

Written By: Alex Serventi



### **INTRODUCTION**

This guide will show you how to remove the Dark Grey case that allows you access to the Screens.



## TOOLS:

• T5 Torx Screwdriver (1)

### **Step 1** — Front Phone Cover



 To remove the front cover, lift up the case with a fingernail in the small slot as shown.

#### **Step 2** — Front Dark Grey Case



 To remove the front grey case, remove the two screws shown with a T5 Torx Screwdriver.

### Step 3



 Pry up the dark grey case with your fingernail until all four snaps around the top are loose.

### Step 4



 Lift up towards the bottom and slide the case off.

To reassemble your device, follow these instructions in reverse order.