



HTC One M9 MicroSD Card Replacement

Use this guide to replace the microSD card on...

Written By: Geoff Wacker



INTRODUCTION

Use this guide to replace the microSD card on your HTC One M9.

TOOLS:

- [SIM Card Eject Tool](#) (1)
-

Step 1 — MicroSD Card



- The microSD card tray is located on the upper right hand side of the phone, above the volume buttons. To open the tray, insert a microSD card eject tool, or a paperclip, into the small hole in the microSD card tray.
- Then press the tool or paperclip to eject the microSD card tray.
 - ⓘ This may require a significant amount of force.
- ✚ When reinserting the microSD card, ensure that it is in the correct orientation to the tray. The electrical connectors should be inserted first, with the microSD card face up.
- ⓘ It is normal for the microSD to sit imperfectly in the tray. The microSD card is easy to reposition within the tray.

To reassemble your device, follow these instructions in reverse order.