

Palm Treo 755p Battery Replacement

How to replace the battery in a Palm Treo 755p.

Written By: Mike Shaw



INTRODUCTION

Remove the outer shell and battery of a Palm Treo 755p.

Step 1 — Battery







- Press the button on the back cover to release the battery cover.
- Slide off the battery cover.

Step 2





Remove the battery by lifting up on one side.

To reassemble your device, follow these instructions in reverse order.