

HP Photosmart D110a Ink Cartridge Replacement

This guide will explain how to replace the ink cartridge on an HP Photosmart D110a printer.

Written By: Tim Wise



This document was generated on 2020-11-20 10:03:19 PM (MST).

INTRODUCTION

Replacing the ink cartridge is easy and requires no technical skill or tools.

Required Tools

None

Step 1 — Ink Cartridge



- In order to remove the old cartridge, open the mouth of the printer by pulling down on it.
- There are two pieces to the mouth, make sure to pull down both.

Step 2





- Press down on the head of the ink cartridge that needs replacing. This will release the cartridge and allow you to pull it out.
- Remember the orientation of the old cartridge. The new cartridge will be placed in the slot with the same orientation.

Step 3



 Place the new cartridge into the slot and press firmly until it pops into place.

To reassemble your device, follow these instructions in reverse order.