



# Motorola SLVR L9 Battery Replacement

This guide will show you how to replace the Motorola SLVR L9 battery.

Written By: Tayler Blanchard



---

## INTRODUCTION

The Battery Replacement Guide provides a list of the tools and parts that you need to replace the battery on the Motorola SLVR L9. As you begin the replacement process, look for the pictures provided with each step to better guide you.



### PARTS:

- [Motorola SLVR L9 Battery](#) (1)

## Step 1 — Battery



- Turn the phone over so that the back of the phone is facing up.

## Step 2



- Press down on the silver battery cover latch located at the top of the phone.
- Pull the battery cover down and away from the latch; then lift it up to remove the battery cover.

## Step 3



- To remove the battery, pull the battery up from the bottom center.

To reassemble your device, follow these instructions in reverse order.