



Amazon Fire HD 8 Battery Replacement

In this guide, we will show you how to safely...

Written By: Dan Shimkus



INTRODUCTION

In this guide, we will show you how to safely remove and replace the battery. Before you start, make sure your device is powered off.

TOOLS:

[Heavy-Duty Spudger](#) (1)
[Heat Gun](#) (1)
[iFixit Opening Tool](#) (1)
[Tweezers](#) (1)
[Spudger](#) (1)

PARTS:

[Amazon Fire HD 8 \(5th Gen\) Battery](#) (1)

Step 1 — Screen



- Heat the edges of the screen with a heat gun on the lowest setting by using sweeping motions from about 8-10 inches away.

 **Make sure you use sweeping motions with the heat gun, instead of hovering over one area.**

Step 2



- After 1-2 minutes, use a plastic opening tool to pry the screen loose. Start at the top right corner and gently pry the screen from the device.

⚠ Be careful not to bend the screen by pushing it too far from the rest of the device.


Step 3



- Slide a plastic opening tool and spudger along the underside of the screen using enough force to peel the screen and the adhesive strip from the other half of the device.

⚠ Be mindful of the orange cable connecting the screen to the mid-bottom of the device.

Step 4



- To remove the screen from the device, use tweezers to gently pull the orange cable from its connection to the screen.

Step 5 — Battery



⚠ Be careful not to bend or puncture the battery.

- Lift the wired connector on the top-right of the battery with just enough pressure to disconnect it from the connector.

