



Dremel 8220 Collet Replacement

If you find yourself unable to insert an attachment head into your device you likely need to replace the collet. This guide will show you how.

Written By: connor anisko



INTRODUCTION

This guide will show you how to replace a defective collet. By following a few simple steps, your collet can be replaced in approximately 5 minutes. No experience is required and only one tool is needed.



TOOLS:

- [Spudger](#) (1)
-

Step 1 — Collet



- Press and hold down on the gear lock button to lock the shaft.

Step 2



- With the lock held down, begin unscrewing the collar wrench.

Step 3



- Remove the collet nut, and poke out the collet.
- ⓘ If the collet is jammed in the collet nut, more force will need to be applied.

For dremel reassembly, follow the guide steps in reverse order.