

Black and Decker FT1000 Type 1 Blower Switch Replacement

Black and Decker only replaces the switch with a complete motor, so this guide will replace the switch with a commonly available switch.

Written By: Scot Henderson



This document was generated on 2020-11-29 08:14:43 PM (MST).

INTRODUCTION

Black and Decker only replaces the switch with a complete motor, so this guide will replace the switch with a commonly available switch.



TOOLS:

Phillips #2 Screwdriver (1)

Step 1 — Black and Decker FT1000 Blower





This is the blower. I have removed the nozzle and strap.

Step 2



Remove Screws.



 Remove rear cover. It helps to hold the plug tight to the front housing so the wires stay in place.

Step 4







- Notice the switch is fine, it's simply the plastic armature that is broken.
- The broken piece is only included with the motor and switch.



- This switch is easy to find. It's just a single position single throw switch.
- I was able to buy it at a home improvement store for \$4.00.
- It even fits nicely in the cutout for the original switch/armature.

Step 6







- Remove the switch/armature.
- Remove the tension plate (the metal piece).
- Put in the switch. The terminals are at a bad angle, so we will bend them to fit.






- Bend slowly and carefully.
- Try it in and see how well it fits. It might need some tweaking.

Step 8





 Now remove the actual electrical switch. No need to worry about the wiring, its just open and closed.



- The black wire gets a new wider terminal and just plugs on.
- The other wire needs to be a bit longer, so it gets an extension and a new terminal.
- I used simple crimp on terminals and splice.

Step 10



• There was not enough room for the terminal to pass by the plastic housing. I just removed a little and then routed the black wire under the switch.

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2020-11-29 08:14:43 PM (MST).