



# Dell Latitude E6410 Screen Assembly Replacement

In this guide, you will be shown how to remove the entire screen assembly from the Dell Latitude e6410 laptop and replace it.

Written By: Esteban Damian



---

## INTRODUCTION

Use this guide to replace the entire Dell Latitude e6410 screen assembly. You will be removing the entire old screen assembly and replacing it with the new screen.

Use this guide only to replace the entire screen assembly. "Screen assembly" refers to the all of the screen components fully assembled into the screen case including the display, camera, and other components.



### TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

## Step 1 — Dell Latitude E6410 Screen Assembly



- Slide both clips in towards each other to remove the battery from the laptop.

**i** It is always important to remove an electronic device's power source when taking it apart to prevent electrocution.

## Step 2



- Remove the two 5 mm Phillip's screws located on the left and right side of the battery socket.



## Step 3




- Remove the two gray squares by sliding each piece towards you.

## Step 4




- Remove the two 5mm Phillip's screws in the bottom right and the top left corners of the back panel.
  - Remove the 3mm Phillip's screw that is near the bottom right corner.
  - Loosen the Phillip's screw that is near the center until the spring pops up, but do not remove it.
  - Detach the back case panel by sliding it away from the battery slot and lifting it out of place.
- ☒ When reattaching the back panel slide it towards the location of the battery instead of away from it while also applying pressure downwards.

## Step 5



- Loosen the two 5mm Phillip's screws near the top right corner that are holding the display cable onto the motherboard.


## Step 6



- Detach the display cord from the motherboard by grabbing the blue tab in between your thumb and index finger and carefully pulling upwards.
- ⚠ Don't pull too hard or you may rip off the tab, but apply enough pressure so that it actually comes off.



## Step 7



- Near the bottom left corner, detach the grey, black, and white wires from the graphics card and the two wires hooked in place by carefully unhooking them or pulling them off.


☑ When reassembling use the second or last picture to reference where each wire goes.

## Step 8



- Carefully unthread the wires detached in the last step from the hooks to completely free them from the laptop.

## Step 9



- Remove the two 5mm Phillip's screws that are in the top right and left corners of the laptop.

## Step 10



- Flip the laptop so that the top is facing up and grab the back two corners of the laptop screen. Pull upwards to remove the screen.

★ When reassembling use the new laptop screen.

To reassemble your device, follow these instructions in reverse order.