



HP Envy 15-u001dx Key Replacement

This guide shows you how to remove keys from your keyboard.

Written By: Dakota Presley



INTRODUCTION

Sometimes keys can become "sticky" or unresponsive from spills and rough usage and need to be removed to clean or replace. This is a more difficult and delicate guide. The underside of the keys are fragile and must be removed with caution or they will break.

TOOLS:

- [Spudger](#) (1)
-

Step 1 — Key



- Use a metal spudger to separate key from keyboard.

⚠ Be sure to remove the white frame underneath the key at the same time or it will break and the key will not snap back into place.

To reassemble your device, follow these instructions in reverse order.