




# Nextbook Premium 7SE Battery Replacement

It is important to note that this guide...

Written By: Walker Karstens




# INTRODUCTION

It is important to note that this guide requires the use of a soldering iron. Be sure you familiarize yourself on how to use a soldering iron.

## TOOLS:

[Desoldering Braid](#) (1)  
[Lead-Free Solder](#) (1)  
[Staples](#) (1)  
[iFixit Opening Tool](#) (1)  
[Soldering Iron](#) (1)  
[Spudger](#) (1)

## Step 1 — Back Cover



- Insert the plastic opening tool into the middle of the bottom edge of the device. The tool should be inserted within the seam between the back and front covers.
- Slide the opening tool to the right and slowly continue to separate the back cover from the device.

 **Avoid prying on the buttons, as they are easily damaged.**

## Step 2



- Pull the cover off of the device once about three quarters of the cover has been pried open using the plastic opening tool.

## Step 3 — Battery



- Remove masking tape from the battery.



## Step 4



- Pry the battery from the base using the nylon spudger and move it away from the motherboard.

⚠ Handle the battery with care to avoid damaging it.

## Step 5



- De-solder the three contact points and remove the battery.

ⓘ See the following guide for instructions on how to solder. [How To Solder and Desolder Connections](#)

⚠ Use caution when operating the soldering iron.

To reassemble your device, follow these instructions in reverse order, being careful when re-soldering the contacts back into place.