Sony Xperia XZ USB Board with Display Flex Replacement

In this video, I'll show you how to fix the uncharged Charging Port of Xperia XZ, and how to replace broken Display flex.

Written By: Witrigs

INTRODUCTION

[video: https://www.youtube.com/watch?v=I2g_SySI3Ic]

In this video, I'll show you how to fix the uncharged Charging Port of Xperia XZ, and how to replace broken Display flex.

TOOLS:

- Plastic Cards (1)
- Phillips #000 Screwdriver (1)
- Heat Gun (1)
- Tweezers (1)
- Spudger (1)
- iFixit Opening Tools (1)

PARTS:

- Original Charging Port with Display Flex (1)

This document was generated on 2021-02-03 05:44:44 AM (MST).

To reassemble your device, follow these instructions in reverse order.

This document was generated on 2021-02-03 05:44:44 AM (MST).