



Dyson V6 Motorhead Collection Bin Replacement

Collection bin holds dirt and other debris collected by the vacuum.

Written By: Addie Hedge



INTRODUCTION

Collection Bin removal, requires battery removal before starting.

Step 1 — Connection Tubing



- Depress the button releasing an end of the connection tubing.
- Pull the connection tubing away from the bottom vacuum head.

Step 2



- Depress the last button, freeing the connection tubing.
- Pull connection tubing away from the upper vacuum head.

Step 3 — Collection Bin



- Pull down on the red release tab.
- ⓘ When the tab is fully engaged, the bottom of the bin should open.

Step 4



- Pull down on the release tab a second time, this time the collection bin should release from the upper vacuum head.

Step 5



- Pull the collection bin away from the upper vacuum head.

To reassemble your device, follow these instructions in reverse order.