

LG Muziq LX570 Rear Case Replacement

Removing the rear case of the LG Muziq LX570 to access the motherboard and keyboard.

Written By: Matthew Cataldo





- Phillips #00 Screwdriver (1)
- iFixit Opening Tools (1)

Step 1 — Battery





- Slide the battery cover release towards top of phone.
- Place one finger at each side of the battery cover.
- Lift and remove the battery cover.

Step 2





Place a finger at the top corner of the battery and lift out of the phone.

Step 3 — Rear Case





- Use the spudger to lift up the two screw covers at the top of the phone.
- Remove all four Phillips#00 (3.3mm) screws with screwdriver.

Step 4







- Use the spudger to lift up the rear case from the phone.
- Note: Rear case is connected on all sides and will have to be detached on all sides before removal.
- Remove the rear case from the device.

To reassemble your device, follow these instructions in reverse order.