



Dyson Cinetic Animal Canister Opening Mechanism Replacement

This piece allows you to open the canister and...

Written By: Allison Turnbaugh



INTRODUCTION

This piece allows you to open the canister and remove vacuumed debris. The canister opening mechanism is an important piece to keep your vacuum running smoothly.

PARTS:

[Dyson DC47 Cinetic Animal Opening Piece](#) (1)

Step 1 — Release the canister



- Press the gray button to release the canister.

Step 2 — Remove the canister



- Remove the canister by lifting it out.

Step 3 — Canister Opening Mechanism



- Turn canister around to find red upside down "U" shaped bar.
- ① If the red bar is broken, pull the pieces out.

To reassemble your device, simply put canister back onto the vacuum body.