




Asus X751L DVD Drive Replacement

Use this guide to replace the DVD drive on your Asus X751L.

Written By: Carl Ravina



INTRODUCTION

This guide will walk you through the process of removing and replacing a faulty DVD Drive.

TOOLS:

- [iFixit Opening Tools](#) (1)
 - [Phillips #00 Screwdriver](#) (1)
-

Step 1 — Keyboard




- With the screen closed, place your laptop upside-down with the front facing you.
- Remove the six 14.6mm Phillips #00 screws.
- Remove the four 6.6mm Phillips #00 screws.

Step 2




- Flip the laptop over and open the lid.
 - Pry around the edges of the laptop base using the plastic opening tool.
- ⚠ Prying too hard can break the plastic clips.

Step 3




- Carefully lift the keyboard up.
 - ⚠ Be very careful when lifting the keyboard up. Two zero insertion force (ZIF) cables are between the keyboard assembly and the motherboard. Do not lift the assembly too high.
- Disconnect the two ZIF connectors from the motherboard using your fingernail to lift the cream-colored tab.

Step 4 — DVD Drive



- With the keyboard panel open, face the laptop with the internal components facing towards you.
- Remove the single 4.6mm Phillips #00 screw.

Step 5



- Pull the optical drive out.

To reassemble your device, follow these instructions in reverse order.