



ZTE Maven Battery Replacement

Follow this guide to remove and replace the battery for the ZTE Maven.

Written By: Gigabit87898

INTRODUCTION

Follow this guide to remove and replace the battery for the ZTE Maven.

For your safety, discharge the battery below 25% before disassembling your phone. This reduces the risk of a dangerous thermal event if the battery is accidentally damaged during the repair. If your battery is swollen, [take appropriate precautions](#).



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
- [iFixit Opening Picks \(Set of 6\)](#) (1)
- [iOpener](#) (1)

Step 1 — Battery



- Remove the back cover.

Step 2



- If inserted, remove the SIM card and SD card.

Step 3



- Remove midframe screws.

Step 4



- Carefully pry between the screen and midframe to release the clips holding it on.

Step 5



- Remove the midframe.

Step 6



- [Heat an iOpener](#) and lay it over the battery for one minute.

Step 7



⚠ Take care not to puncture or bend the battery with your tool—a punctured or bent battery may leak dangerous chemicals or cause a thermal event.

- Carefully, with a pry pick, pry under the battery to cut the adhesive underneath it.
- If you are having trouble, apply a heated iOpener onto the battery for another minute, then try again.
- You can also apply a few drops of high concentration isopropyl alcohol to the edges of the battery to help soften the adhesive.

Step 8



- Remove the battery.

⚠ Do not reuse the battery after it has been removed, as doing so is a potential safety hazard. Replace it with a new battery.

To reassemble your device, follow these instructions in reverse order.